


# Maytag PAV5158AWW 05 - CONTROL PANEL



Maytag [Residential Maytag PAV5158AWW Washer Parts](#) Parts Diagram 05 - CONTROL PANEL  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">21001851</a>			Panel, Control
2	25-3092	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
"	<a href="#">21001519</a>			Endcap
3	<a href="#">21001523</a>			Endcap
"	25-3092	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
4	<a href="#">21001852</a>			Switch, Temperature
"	25-3092	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
5	<a href="#">21001882</a>			Switch, Pressure
"	<a href="#">21001554</a>			Switch, Water Level
"	25-3092	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
6	<a href="#">21001600</a>			Skirt, Timer
7	21001594	<a href="#">21001972</a>		Knob, Timer
8	21001227	<a href="#">21001673</a>		Switch, Speed 4 Pos Rotary
9	21001745		Not Available	FRAME (WHT)

10	25-3092	<a href="#">90767</a>	Screw, 8A X 3/8 HeX Washer Head Tapping
"	<a href="#">25-3457</a>		Screw, Sems
"	<a href="#">21001527</a>		Shield, Rear
11	<a href="#">21001595</a>		Timer
"	25-3092	<a href="#">90767</a>	Screw, 8A X 3/8 HeX Washer Head Tapping
12	21001525	<a href="#">21002196</a>	Knob-Selector
13	<a href="#">21001603</a>		Shield, Control
"	<a href="#">21001517</a>		Shield, Control
14	<a href="#">31001397</a>		Buzzer
15	<a href="#">21001813</a>		Switch, Rocker
16	<a href="#">21001949</a>		Harness, Wiring
"	<a href="#">21001853</a>		Harness, Wire

*the laundry company*<sup>®</sup>

*the laundry company*<sup>®</sup>

*the laundry company*<sup>®</sup>