


Maytag PAVT344AWW 09 - WIRING INFORMATION



SWITCH AND TIMER SEQUENCE

TO CHANGE TIMER POSITION PUSH KNOB IN AND TURN CLOCKWISE (ALL TIMER CONTACTS WILL OPEN)

[Maytag Residential Maytag PAVT344AWW Washer Parts](#) Parts Diagram 09 - WIRING INFORMATION
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
NI	15003247		Not Available	WIRING INFORMATION

