


# Maytag PDET910AYW 02 - CABINET & FRONT PANEL



Maytag Residential Maytag PDET910AYW Dryer Parts Parts Diagram 02 - CABINET & FRONT PANEL  
 Click on the part number to view part

| Item | Original Part Number     | Replaced By              | Status | Part Description            |
|------|--------------------------|--------------------------|--------|-----------------------------|
| 1    | <a href="#">503688</a>   |                          |        | Screw, 10B-16 X .34 I       |
| 2    | 37001155                 | <a href="#">37001284</a> |        | Cabinet As Pack             |
| 3    | <a href="#">505187</a>   |                          |        | Locator, Panel              |
| 4    | 32671                    | <a href="#">Y014874</a>  |        | Screw, Idler Arm And Sleeve |
| 5    | <a href="#">Y56128</a>   |                          |        | Pad, Bumper                 |
| 6    | <a href="#">500003</a>   |                          |        | Hinge, Top                  |
| 7    | 32671                    | <a href="#">Y014874</a>  |        | Screw, Idler Arm And Sleeve |
| 8    | <a href="#">503293</a>   |                          |        | Plate, Access Cover         |
| 9    | <a href="#">504034</a>   |                          |        | Clip, Wire                  |
| 10   | <a href="#">25-7220</a>  |                          |        | Clip, Cabinet Top           |
| 11   | <a href="#">37001030</a> |                          |        | Screw, No.8ab-16 x 3/4 Fh   |
| 12   | <a href="#">505187</a>   |                          |        | Locator, Panel              |
| 13   | <a href="#">Y503676</a>  |                          |        | Hinge, Door And Top         |
| 14   | 213280                   | <a href="#">204439</a>   |        | Screw And Fstner Assembly   |
| 15   | 504005                   | <a href="#">511056</a>   |        | Seal Front Panel            |
| 16   | <a href="#">37001028</a> |                          |        | Seal And Liner, Assembly    |

|    |                          |                           |                        |
|----|--------------------------|---------------------------|------------------------|
| 17 | <a href="#">37001029</a> |                           | Door, Dryer            |
| 18 | <a href="#">27001200</a> |                           | Screw                  |
| 19 | <a href="#">20530</a>    |                           | Screw, 10-24 x 3/8 Hex |
| 20 | Y504570                  | <a href="#">W10169313</a> | Switch-Dor             |
| 21 | <a href="#">503126</a>   |                           | Plug, Hinge Hole       |
| 22 | 54660                    | <a href="#">LA-1003</a>   | Door Catch Kit         |
| 23 | 500039                   | <a href="#">510181</a>    | Strike Doormetal       |
| 24 | <a href="#">40116201</a> |                           | Bracket, Door Strike   |
| 25 | <a href="#">33001241</a> |                           | Handle, Door           |
| 26 | <a href="#">37001154</a> |                           | Front Panel - White    |

