


# Maytag PYE4557AYW 03 - DOOR



Maytag Residential Maytag PYE4557AYW Dryer Parts Parts Diagram 03 - DOOR  
 Click on the part number to view part

| Item | Original Part Number     | Replaced By               | Status        | Part Description        |
|------|--------------------------|---------------------------|---------------|-------------------------|
| 1    | 53-0726                  | <a href="#">31001771</a>  |               | Panel, Front            |
| 2    | <a href="#">53-0120</a>  |                           |               | Clip, Front Panel       |
| 3    | <a href="#">25-7220</a>  |                           |               | Clip, Cabinet Top       |
| 4    | <a href="#">53-0200</a>  |                           |               | Sleeve, Locator Pin     |
| "    | 25-0224                  | <a href="#">3400029</a>   |               | Nut, Adapter Plate      |
| "    | <a href="#">53-0643</a>  |                           |               | Pin, Locator            |
| 5    | <a href="#">33001809</a> |                           |               | Sensor Bar Assembly     |
| 6    | 31001502                 | <a href="#">12001324</a>  |               | Duct Kit, Collector     |
| "    | 25-7810                  | <a href="#">415013-35</a> |               | Screw                   |
| 7    | <a href="#">53-0204</a>  |                           |               | Seal                    |
| 8    | <a href="#">LA-1005</a>  |                           |               | Switch Kit              |
| 9    | <a href="#">53-0918</a>  |                           |               | Filter, Lint            |
| 10   | 53-0281                  | <a href="#">31001747</a>  |               | Seal Assembly           |
| 11   | <a href="#">53-0154</a>  |                           |               | Panel, Outer Door       |
| "    | 25-7752                  | <a href="#">3196169</a>   |               | Screw, Element          |
| 12   | 53-0912                  |                           | Not Available | PANEL, INNER DOOR (WHT) |

|    |                          |                           |                               |
|----|--------------------------|---------------------------|-------------------------------|
| 13 | <a href="#">53-0119</a>  |                           | Clip, Hinge                   |
| 14 | <a href="#">21001281</a> |                           | Damper, Sound Pad             |
| "  | <a href="#">53-1490</a>  |                           | Door Pad                      |
| 15 | <a href="#">53-1491</a>  |                           | Door Pad                      |
| 16 | 53-0648                  | <a href="#">31001529</a>  | Seal, Door                    |
| 17 | <a href="#">25-7889</a>  |                           | Plug Button                   |
| 18 | <a href="#">53-0927</a>  |                           | Handle, Door                  |
| "  | 25-7810                  | <a href="#">415013-35</a> | Screw                         |
| 19 | <a href="#">25-7809</a>  |                           | Screw, No.6-20 1/2 Flthd Torx |
| "  | <a href="#">53-1492</a>  |                           | Hinge, Dryer Door             |
| 20 | 53-0121                  | Not Available             | TWIN NUT                      |
| 21 | <a href="#">LA-1003</a>  |                           | Door Catch Kit                |
| "  | 53-2364                  | <a href="#">LA-1003</a>   | Door Catch Kit                |
| 22 | 53-0187                  | <a href="#">LA-1003</a>   | Door Catch Kit                |
| 23 | <a href="#">53-0148</a>  |                           | Switch, Door                  |
| 24 | 63-5990                  | <a href="#">31001319</a>  | Clip, Switch                  |
| 25 | <a href="#">33-2653</a>  |                           | Bumper, Cabinet               |
| 26 | 31001280                 | <a href="#">12001324</a>  | Duct Kit, Collector           |

