


Maytag PYG2300AGW 04 - DOOR AND FRONT PANEL



Maytag Residential Maytag PYG2300AGW Dryer Parts Parts Diagram 04 - DOOR AND FRONT PANEL

Click on the part number to view part

| Item | Original Part Number | Replaced By | Status | Part Description |
|------|--------------------------|---------------------------|---------------|-------------------------------|
| 1 | 53-0726 | 31001771 | | Panel, Front |
| 2 | 53-0120 | | | Clip, Front Panel |
| 3 | 31001526 | | | Lock, Top |
| 4 | 33-2653 | | | Bumper, Cabinet |
| 5 | 31001541 | | | Seal, Blower/Collector Duct |
| 6 | 25-7810 | 415013-35 | | Screw |
| " | 12001324 | | | Duct Kit, Collector |
| 7 | 53-0204 | | | Seal |
| 8 | LA-1005 | | | Switch Kit |
| 9 | 53-0918 | | | Filter, Lint |
| 10 | 31001637 | | | Seal Assembly, Cylinder Front |
| 11 | 25-7752 | 3196169 | | Screw, Element |
| " | 53-0154 | | | Panel, Outer Door |
| 12 | 53-0912 | | Not Available | PANEL, INNER DOOR (WHT) |
| 13 | 53-0119 | | | Clip, Hinge |
| 14 | 53-1490 | | | Door Pad |

| | | | |
|----|--------------------------|---------------------------|-------------------------------|
| 15 | 53-1491 | | Door Pad |
| 16 | 31001529 | | Seal, Door |
| 17 | 25-7889 | | Plug Button |
| 18 | 25-7810 | 415013-35 | Screw |
| " | 53-0927 | | Handle, Door |
| 19 | 53-1492 | | Hinge, Dryer Door |
| " | 25-7809 | | Screw, No.6-20 1/2 Flthd Torx |
| 20 | 31001786 | 98006631 | Screw |
| " | 53-0121 | Not Available | TWIN NUT |
| 21 | 53-2364 | LA-1003 | Door Catch Kit |
| 22 | 53-0187 | LA-1003 | Door Catch Kit |
| 23 | 31001467 | 31001757 | Switch, Door |
| 24 | 31001319 | | Clip, Switch |

the laundry company[®]

the laundry company[®]

the laundry company[®]