


Maytag PYG2300AWW 02 - CONTROL PANEL



Maytag [Residential Maytag PYG2300AWW Dryer Parts](#) Parts Diagram 02 - CONTROL PANEL
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	31001463			Panel, Control
2	21001519			Endcap
"	25-3092	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
3	21001523			Endcap
"	25-3092	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
4	53-1639			Buzzer Assembly
5	25-3092	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
"	31001348	31001449		Switch, Selector
6	31001385	37001184		Timer Knob And Skirt Assembly
7	53-2504	31001193		Pad, Shield
"	21001517			Shield, Control
"	31001193			Pad, Shield
8	25-7851			Speedclip, End Cap To Top
9	21001604		Not Available	FRAME, CONTROL PANEL

9	21001004	Not Available	(WHT)
10	21001527		Shield, Rear
"	25-3092	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
"	25-3457		Screw, Sems
11	53-1810		Timer
"	25-3092	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
12	21001525	21002196	Knob-Selector
13	16008334	Not Available	MANUAL, SRVC DRYER-NO REFUND
"	31001458		Manual, Use And Care
"	21001419	Not Available	MANUAL, LAUNDERING TIPS
"	16009627		Manual, Use And Care
14	31001492		Harness, Wire
15	12002417		Wire Kit

