


# Maytag PYG3200AWW 02 - CONTROL PANEL



Maytag [Residential Maytag PYG3200AWW Dryer Parts](#) Parts Diagram 02 - CONTROL PANEL  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">31001389</a>			Panel, Control
2	<a href="#">21001519</a>			Endcap
"	25-3092	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
3	<a href="#">21001523</a>			Endcap
"	25-3092	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
4	<a href="#">31001397</a>			Buzzer
5	25-3092	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
"	31001399	<a href="#">31001483</a>		Resistor Assembly Temperature
"	31001398	<a href="#">31001447</a>		Switch, Temperature
6	31001385	<a href="#">37001184</a>		Timer Knob And Skirt Assembly
7	<a href="#">21001603</a>			Shield, Control
"	<a href="#">31001193</a>			Pad, Shield
"	53-2504	<a href="#">31001193</a>		Pad, Shield

8	<a href="#">25-7851</a>		Speedclip, End Cap To Top
9	21001604	Not Available	FRAME, CONTROL PANEL (WHT)
10	<a href="#">25-3457</a>		Screw, Sems
"	25-3092	<a href="#">90767</a>	Screw, 8A X 3/8 HeX Washer Head Tapping
"	<a href="#">21001527</a>		Shield, Rear
11	25-3092	<a href="#">90767</a>	Screw, 8A X 3/8 HeX Washer Head Tapping
"	53-1815	<a href="#">31001513</a>	Timer
12	21001525	<a href="#">21002196</a>	Knob-Selector
13	<a href="#">31001190</a>		Switch, Two Position Rotary
"	25-3092	<a href="#">90767</a>	Screw, 8A X 3/8 HeX Washer Head Tapping
14	16008334	Not Available	MANUAL, SRVC DRYER-NO REFUND
"	<a href="#">31001458</a>		Manual, Use And Care
"	21001419	Not Available	MANUAL, LAUNDERING TIPS
"	<a href="#">16009627</a>		Manual, Use And Care
15	<a href="#">12002417</a>		Wire Kit

