


Maytag PYG3300AWW 02 - CONTROL PANEL



Maytag [Residential Maytag PYG3300AWW Dryer Parts](#) Parts Diagram 02 - CONTROL PANEL
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	31001464			Panel, Control
2	21001519			Endcap
"	25-3092	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
3	21001523			Endcap
"	25-3092	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
4	31001397			Buzzer
5	31001399	31001483		Resistor Assembly Temperature
"	31001398	31001447		Switch, Temperature
"	25-3092	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
6	31001385	37001184		Timer Knob And Skirt Assembly
7	21001603			Shield, Control
"	31001193			Pad, Shield
"	53-2504	31001193		Pad, Shield

8	25-7851		Speedclip, End Cap To Top
9	21001604	Not Available	FRAME, CONTROL PANEL (WHT)
10	25-3457		Screw, Sems
"	21001527		Shield, Rear
"	25-3092	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
11	25-3092	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
"	53-1815	31001513	Timer
12	21001525	21002196	Knob-Selector
13	31001190		Switch, Two Position Rotary
"	25-3092	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
14	16008334	Not Available	MANUAL, SRVC DRYER-NO REFUND
"	21001419	Not Available	MANUAL, LAUNDERING TIPS
15	12002417		Wire Kit

