


Maytag PYG4557AWW 02 - CONTROL PANEL



Maytag [Residential Maytag PYG4557AWW Dryer Parts](#) Parts Diagram 02 - CONTROL PANEL
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	31001524			Panel, Control
2	21001519			Endcap
"	25-3092	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
3	21001523			Endcap
"	25-3092	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
4	31001397			Buzzer
5	25-3092	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
"	31001398	31001447		Switch, Temperature
"	31001704			Resistor Assembly Temperature
6	31001385	37001184		Timer Knob And Skirt Assembly
7	21001603			Shield, Control
8	31001507			Bracket, Circuit Board
9	21001604		Not Available	FRAME, CONTROL PANEL (WHT)

10	25-3092	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
"	21001527		Shield, Rear
"	25-3457		Screw, Sems
11	25-3092	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
"	31001513		Timer
12	21001525	21002196	Knob-Selector
13	31001190		Switch, Two Position Rotary
"	25-3092	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
14	33001212		Board, Control-Moisture Sensor

the laundry company[®]

the laundry company[®]

the laundry company[®]