



[Maytag Residential Maytag PYGS244AWW Dryer Parts Parts Diagram 06 - SUPPLEMENTAL INFORMATION](#)
Click on the part number to view part

| Item | Original Part Number | Replaced By | Status | Part Description |
|------|--------------------------|-------------|---------------|------------------------------|
| 1 | 53-4343 | | Not Available | MANUAL, USE & CARE |
| " | 16008334 | | Not Available | MANUAL, SRVC DRYER-NO REFUND |
| 2 | 53-3724 | | | Lead Assembly |
| " | 31001559 | | Not Available | LEAD ASSEMBLY (BUZZER) |
| " | 21001980 | | | Lead Assembly |
| 4 | 31001547 | | | Cord, Power |
| 5 | 12002417 | | | Wire Kit |

