


Maytag PYGT344AWW 02 - CONTROL PANEL



Maytag [Residential Maytag PYGT344AWW Dryer Parts](#) Parts Diagram 02 - CONTROL PANEL
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	31001549			Panel, Control
2	21001519			Endcap
"	25-3092	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
3	25-3092	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
"	21001523			Endcap
4	53-1639			Buzzer Assembly
5	31001550	37001184		Timer Knob And Skirt Assembly
6	25-3092	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
"	31001190			Switch, Two Position Rotary
7	21002005			Frame, Control Panel
8	21001527			Shield, Rear
"	25-3092	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
9	25-3092	90767		Screw, 8A X 3/8 HeX Washer Head Tapping

"	31001513		Timer
10	31001193		Pad, Shield
"	21001603		Shield, Control
11	21001954		Knob, Selector
12	25-3092	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
"	31001447		Switch, Temperature
"	31001704		Resistor Assembly Temperature
13	22003977	74010226	Switch, Rocker W/Shield
14	21001978		Lead Assembly
"	31001557		Lead Assembly
"	31001559	Not Available	LEAD ASSEMBLY (BUZZER)
"	31001491		Harness, Wire

the laundry company[®]

the laundry company[®]

the laundry company[®]