


# Maytag SAV4655AWW 02 - CONTROL PANEL



Maytag Residential Maytag SAV4655AWW Washer Parts Parts Diagram 02 - CONTROL PANEL  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	27001110		Not Available	CONSOLE (WHT)
2	33001855	<a href="#">33002917</a>		Screw, No.10-16
"	<a href="#">27001050</a>			Facia Ground Wire Assembly
"	<a href="#">27001176</a>			Facia
3	27001112	<a href="#">27001087</a>		Knob, Cap
4	27001127	<a href="#">27001203</a>		Switch, Pressure
5	33001855	<a href="#">33002917</a>		Screw, No.10-16
"	<a href="#">27001113</a>			Timer
6	<a href="#">27001051</a>			Back Panel, Hood/Console
7	<a href="#">27001103</a>			Switch, Rotary
8	<a href="#">27001154</a>			Switch, Temperature
9	27001090	<a href="#">22003993</a>		Timer Knob
10	<a href="#">22002997</a>			Pin, Locking
"	27001092		Not Available	SKIRT, TIMER KNOB
11	27001115	<a href="#">27001126</a>		Knob, Selector
12	<a href="#">33001623</a>			Buzzer, Non-Adjustable

13	<a href="#">27001114</a>	Switch, Rotary
14	<a href="#">22003981</a>	Switch, Momentary Rocker
15	22003977	<a href="#">74010226</a> Switch, Rocker W/Shield
16	<a href="#">27001142</a>	Cord, Power

