


Maytag SAV4655EWQ 02 - CONTROL PANEL



Maytag [Residential Maytag SAV4655EWQ Washer Parts](#) Parts Diagram 02 - CONTROL PANEL
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	37001115			Console
2	33001855	33002917		Screw, No.10-16
"	27001050			Facia Ground Wire Assembly
"	27001213			Facia
3	27001189			Cap, Timer Knob
4	27001127	27001203		Switch, Pressure
5	27001113			Timer
"	33001855	33002917		Screw, No.10-16
6	27001051			Back Panel, Hood/Console
7	27001103			Switch, Rotary
8	27001114			Switch, Rotary
9	22003952			Knob, Timer
10	22002997			Pin, Locking
"	27001191			Skirt, Timer Knob
11	37001116	27001126		Knob, Selector
12	33001623			Buzzer, Non-Adjustable

13	27001197	Switch, Temperature
14	22003982	Switch, Momentary Rocker
15	27001208	Control, Atc Board
16	22003978	Switch, Rocker
17	27001142	Cord, Power

