


# Maytag SAV4655EWW 06 - TOP AND DOOR SWITCH



Maytag Residential Maytag SAV4655EWW Washer Parts Parts Diagram 06 - TOP AND DOOR SWITCH  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	27001116		Not Available	LID (WHT)
2	40034901	<a href="#">40034901P</a>		Assembly- Lid
3	501086	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
4	<a href="#">40038001</a>			Bumper
5	40039201	<a href="#">W10119828</a>		Screw, Lid Hinge Mounting
6	<a href="#">40008201</a>			Bushing, Hinge
7	<a href="#">40094002</a>			Hinge, Lid Left Stop
8	<a href="#">40094101</a>			Hinge, Lid Right Pass
9	<a href="#">27001117</a>			Dispenser, Bleach
10	<a href="#">40009701</a>			Arm, Lid Switch
11	<a href="#">27001182</a>			Top
12	<a href="#">40102101</a>			Cap, Hinge
13	<a href="#">40009801</a>			Holder, Lid Switch
14	<a href="#">40040701</a>			Screw, Tapping No.6b-20
15	501086	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping

