


Maytag SAV4710AWW 02 - CONTROL PANEL



Maytag Residential Maytag SAV4710AWW Washer Parts Parts Diagram 02 - CONTROL PANEL
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	27001110		Not Available	CONSOLE (WHT)
2	33001855	33002917		Screw, No.10-16
"	27001177			Facia
"	27001050			Facia Ground Wire Assembly
3	27001112	27001087		Knob, Cap
4	27001127	27001203		Switch, Pressure
"	27001047			Switch, Pressure
5	27001113			Timer
6	27001051			Back Panel, Hood/Console
7	27001103			Switch, Rotary
8	27001114			Switch, Rotary
9	27001090	22003993		Timer Knob
10	22002997			Pin, Locking
"	27001092		Not Available	SKIRT, TIMER KNOB
11	27001115	27001126		Knob, Selector
12	33001623			Buzzer, Non-Adjustable

13	27001059		Switch, Temperature
14	22003981		Switch, Momentary Rocker
15	40131001		Board, Atc 3 Point
16	22003977	74010226	Switch, Rocker W/Shield
"	27001142		Cord, Power

