


# Maytag SAV5300AWW 02 - CONTROL PANEL



Maytag Residential Maytag SAV5300AWW Washer Parts Parts Diagram 02 - CONTROL PANEL  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">503674W</a>			Cover, Top
2	501086	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
3	<a href="#">40077101</a>			Switch, Temperature Select
4	<a href="#">40055101</a>			Switch, Pressure
5	501086	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
6	40058901	<a href="#">R0131012</a>		Timer
7	501086	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
8	<a href="#">40012702W</a>			Endcap
"	40012701W		Not Available	ENDCAP (RT-WHT)
9	501086	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
10	<a href="#">40039601</a>			Support, Control Panel
11	<a href="#">40136701W</a>			Panel, Control
12	<a href="#">40013703W</a>			Dial, Timer Knob
13	<a href="#">40014003W</a>			Knob, Speed Switch

14	<a href="#">38424W</a>		Switch, Rocker
16	<a href="#">40013403W</a>		Knob, Selector
18	<a href="#">27001181</a>		Harness, Wiring
"	40100001	<a href="#">27001041</a>	Harness, Base Wire
19	40098701	<a href="#">27001142</a>	Cord, Power

