


Maytag SAV5401AWW 02 - CONTROL PANEL



Maytag Residential Maytag SAV5401AWW Washer Parts Parts Diagram 02 - CONTROL PANEL
 Click on the part number to view part

| Item | Original Part Number | Replaced By | Status | Part Description |
|------|--------------------------|--------------------------|---------------|------------------------------|
| 1 | 33002286 | | Not Available | CONSOLE (WHT) |
| 2 | 27001050 | | | Facia Ground Wire Assembly |
| " | 27001049 | | | Graphic Control Panel, Facia |
| 3 | 22001825 | | | Temperature Switch - Rotary |
| 4 | 27001047 | | | Switch, Pressure |
| 5 | 33001855 | 33002917 | | Screw, No.10-16 |
| " | 27001048 | 27001060 | | Timer |
| 6 | 27001051 | | | Back Panel, Hood/Console |
| 7 | 22001794 | | | Switch, Rotary |
| 8 | 22002578 | | | Switch, Speed |
| 9 | 22002996 | 22003952 | | Knob, Timer |
| 10 | 22002995 | | Not Available | SKIRT, TIMER KNOB (WHT) |
| " | 22002997 | | | Pin, Locking |
| 11 | 22003913 | 22001663 | | Knob, Selector Switch |
| 12 | 22001664 | | | Timer Knob Insert/Cap |
| 13 | 40098701 | 27001142 | | Cord, Power |