


Maytag SAV5600AWW 02 - CONTROL PANEL



Maytag Residential Maytag SAV5600AWW Washer Parts Parts Diagram 02 - CONTROL PANEL
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	503674W			Cover, Top
2	501086	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
3	40046601			Switch, Temperature Select
4	40077201			Switch, Pressure
5	501086	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
6	40059001	40059002		Timer, Mallory 13 CYC
7	501086	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
8	40012701W		Not Available	ENDCAP (RT-WHT)
"	40012702W			Endcap
9	501086	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
10	40039601			Support, Control Panel
11	40136801W			Panel, Control
12	40013703W			Dial, Timer Knob
13	40014003W			Knob, Speed Switch

14	38424W		Switch, Rocker
15	40039501		Switch, Speed
16	40013403W		Knob, Selector
18	40100001	27001041	Harness, Base Wire
"	40100601		Harness, Hood Wire
19	40098701	27001142	Cord, Power

