


Maytag SDE4606AZW 09 - WIRING INFORMATION (SERIES 11)

CIRCUIT	FUNCTION	60	120	180	240	300	
①	GY-PK SIGNAL	[Wiring Diagram]					
	GY-YL DRIVE MOTOR	[Wiring Diagram]					
②	YL-OR ELEC CONTROL	[Wiring Diagram]					
	BK-RD HEATER	[Wiring Diagram]					
③	BK-RD HEATER	[Wiring Diagram]					
	BK-PJ PRESS CARE	[Wiring Diagram]					
□ CONTACTS OPEN ■ CONTACTS CLOSED		REGULAR FABRICS	TIME DRY	PERMANENT PRESS	PRESS CARE		



NOTE: Power cord provided on select models only.

***TEMP SWITCH DETAILS**

REGULAR	BU - RD
MEDIUM	BU - RD, PU - WH with Heater
DELICATE	BU - RD, PU - WH
ALL P/UP	No Control Mts

CAUTION: Label all wires prior to disconnection when servicing controls. Wiring errors can cause improper and dangerous operation. Verify proper operation after servicing.

2201007 A

Maytag Residential Maytag SDE4606AZW Dryer Parts Parts Diagram 09 - WIRING INFORMATION (SERIES 11)
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
NI	15003414		Not Available	WIRING INFORMATION

