


# Maytag SDG2606AWW 02 - CONTROL PANEL



Maytag [Residential Maytag SDG2606AWW Dryer Parts](#) Parts Diagram 02 - CONTROL PANEL  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">37001099</a>			Facia
2	<a href="#">37001067</a>			Dial, Timer
3	<a href="#">37001068</a>			Knob, Timer
4	27001112	<a href="#">27001087</a>		Knob, Cap
5	27001115	<a href="#">27001126</a>		Knob, Selector
6	37001031	<a href="#">3370225</a>		Screw
7	<a href="#">33001632</a>			Timer
8	<a href="#">37001072</a>			Panel, Back
9	27001110		Not Available	CONSOLE (WHT)
10	<a href="#">33001642</a>			Switch, Temperature
11	37001090	<a href="#">33001618</a>		Switch- PU
12	<a href="#">37001091</a>			Button, Push-To-Start
13	<a href="#">33001623</a>			Buzzer, Non-Adjustable
"	501086	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping