


# Maytag SDG3606AWQ 02 - CONTROL PANEL



Maytag [Residential Maytag SDG3606AWQ Dryer Parts](#) Parts Diagram 02 - CONTROL PANEL  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">37001114</a>			Facia
2	<a href="#">37001118</a>			Dial, Timer
3	<a href="#">37001120</a>			Knob, Timer
4	<a href="#">27001189</a>			Cap, Timer Knob
5	37001116	<a href="#">27001126</a>		Knob, Selector
6	37001031	<a href="#">3370225</a>		Screw
7	37001089	<a href="#">Y2200920</a>		Timer
8	Y22002339	<a href="#">8534058</a>		Screw
"	<a href="#">37001072</a>			Panel, Back
9	<a href="#">37001115</a>			Console
10	<a href="#">22001794</a>			Switch, Rotary
11	37001117	<a href="#">33001618</a>		Switch- PU
12	<a href="#">33002435</a>			Button, Push-To-Start
13	501086	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
"	<a href="#">33001623</a>			Buzzer, Non-Adjustable
14	<a href="#">33001640</a>			Switch, Temperature

