


Maytag SDG3606AWW 02 - CONTROL PANEL



Maytag [Residential Maytag SDG3606AWW Dryer Parts](#) Parts Diagram 02 - CONTROL PANEL
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	37001103			Facia
2	37001067			Dial, Timer
3	37001068			Knob, Timer
4	27001112	27001087		Knob, Cap
5	27001115	27001126		Knob, Selector
6	37001031	3370225		Screw
7	37001089	Y2200920		Timer
8	Y22002339	8534058		Screw
"	37001072			Panel, Back
9	27001110		Not Available	CONSOLE (WHT)
10	22001794			Switch, Rotary
11	37001090	33001618		Switch- PU
12	37001091			Button, Push-To-Start
13	501086	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
"	33001623			Buzzer, Non-Adjustable
14	33001640			Switch, Temperature

