


Maytag SDG5401AXW 02 - CONTROL PANEL



Maytag [Residential Maytag SDG5401AXW Dryer Parts](#) Parts Diagram 02 - CONTROL PANEL
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	37001026	22003950		Facia, Control Panel
"	Y22002339	8534058		Screw
2	37001043	22003951		Dial Skirt
3	22003915			Timer Knob
4	22001664			Timer Knob Insert/Cap
5	22003913	22001663		Knob, Selector Switch
6	37001031	3370225		Screw
7	33001632			Timer
8	216423	3370225		Screw
"	22002529		Not Available	CONSOLE BACK PANEL
9	33002286		Not Available	CONSOLE (WHT)
10	33001641			Switch, Temperature
11	33001861	33001618		Switch- PU
12	33001619	37001071		Button, Push-To-Start
13	501086	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
"	33001623			Buzzer, Non-Adjustable

