


Maytag SE7800 04 - CABINET, RELAYS & DRYER STAND

SECTION: CABINET, RELAYS & DRYER STAND

MODEL: SE7800 S67800



Issue Date: 12/90

6

Maytag Residential Maytag SE7800 Stacked Washer and Dryer Parts Diagram 04 - CABINET, RELAYS & DRYER STAND

Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
3	Y313561			Screw---NA
4	314470		Not Available	COVER, TERMINAL
5	308055			Cabinet
6	312548			Fastener-Access Panel To CA
8	400008			Block, Terminal
9	211168	W10139210		Screw, 8-18 X 5/16
10	314532		Not Available	MOUNTING BRACKET
11	215948		Not Available	GROMMET
12	315264	74006784		Clip, Harness
13	215075			Fastener, Control Panel To Console
14	Y310632	1163839		Screw
15	314489			Guide, Pin
16	214872			Palnut, End Cap Note: Nut, Lamp Holder
17	Y313262	W10116752		Retainer-

18	211252		Screw, Ground Wire
19	207784	Not Available	WIRE HARNESS
20	314477		Screw, Access Panel
21	306072	Not Available	ACCESS PANEL-WHITE
22	314482		Fastener, Spring
23	314498		Pad, Dryer Leg
24	306073	Not Available	LEG ASSM, (RT-WHT)
25	Y052740	62739	Nut, Lock
26	Y314137		Foot, Rubber
27	Y305086		Adjustable Leg And Nut
28	210684		Foot, Adjustable Leg
29	Y302699	22003428	Leg, Adjustable
30	Y052721		Nut, Terminal Block Plate
31	210385		Lock Nut For Adjustable Leg
32	314499	Not Available	BRACE
33	214354		Screw, Top Cover To Cabnt.
34	Y306110		Stand, Dryer
35	306074	Not Available	LEG ASSM, LEFT-WHITE
36	303846	22003781	Screw, Ground Strap
37	314663	214354	Screw, Top Cover To Cabnt.
38	305205	694419	Mini-Buzzer
39	211168	W10139210	Screw, 8-18 X 5/16
40	305168	33002916	Power Cord, Canadian 240V
41	314505	Not Available	INSTRUCTION LABEL
42	214519		LABEL, ELECTRICAL INSTR. PART NOT USED-GAS MODELS ONLY
43	314486	Not Available	LABEL
44	306128	Not Available	BRACE FOR STAND- ACCESSORY
45	215960	Not Available	STRAIN RELIEF
46	215953	Not Available	SCREW

