


Maytag SE7800 11 - INNER/OUTER TUB,AGITATOR & WTR LEVEL SWTH

SECTION: INNER TUB, OUTER TUB, AGITATOR & WATER LEVEL SWITCH
 MODEL: SE7800 SG7800



Issue Date: 12/90

30

Maytag Residential Maytag SE7800 Stacked Washer and Dryer Parts Parts Diagram 11 - INNER/OUTER TUB,AGITATOR & WTR LEVEL SWTH
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	215733			Dispensing Cup
2	215721			Dispensing Cap
3	207538			Agitator W/Lock Screw
4	206478		Not Available	SCREW & WASHER FOR AGITATOR
5	211100			Washer, Outer Tub
6	Y054867			Washer, Lock
7	204013	6-2040130		Tub Bearin
8	200824	6-2040130		Tub Bearin
9	211130			Bearing Liner, Tub Bearing
10	201537	6-2095720		Mounting S
11	204012	6-2095720		Mounting S
12	202521	6-2095720		Mounting S
13	211047	6-2110472		Nut- Clamp
14	Y0A4298	6-0A57420		Seal- Agitator
15	207830		Not Available	INNER TUB W/PLUG

16	207787	12002304	Switch-WL
17	410296	596669	Clamp, Manifold
18	206405		Outer Tub
19	215258	22001616	Tube, Air
20	211641		Clamp, 1-1/16"
21	213045		Hose, Outer Tub Part Not Used
22	200900	616099	Clamp
23	205161	489503	Clamp
24	214434		Spout, Deflector
25	214495		Tube, Inlet To Tub
26	211210		Washer, Clamping Nut
27	Y015666		Washer, Retaining -
28	Y015667		Retaining Ring
29	207219		Filter, Self-Cleaning

