


Maytag SG1000 12 - INNER/TUB,AGITATOR & WTR LEVEL SWTH

SECTION: INNER TUB, OUTER TUB, AGITATOR & WATER LEVEL SWITCH
 MODEL: SE-SG1000

P/N 56287R1



Maytag Residential Maytag SG1000 Stacked Washer and Dryer Parts Diagram 12 - INNER/OUTER TUB,AGITATOR & WTR LEVEL SWTH
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	215733			Dispensing Cup
"	212815		Not Available	DISPENSER CUP
2	206823	Y207427		Lint Filter Shallow
"	203320		Not Available	LINT FILTER - DISPENSER
3	205054		Not Available	AGITATOR
"	206843	207538		Agitator W/Lock Screw
4	206478		Not Available	SCREW & WASHER FOR AGITATOR
5	211100			Washer, Outer Tub
6	Y054867			Washer, Lock
7	204013	6-2040130		Tub Bearin
8	200824	6-2040130		Tub Bearin
9	211130			Bearing Liner, Tub Bearing
10	201537	6-2095720		Mounting S
11	204012	6-2095720		Mounting S
12	202521	6-2095720		Mounting S

13	211047	6-2110472	Nut- Clamp
14	Y0A4298	6-0A57420	Seal- Agitator
15	207830	Not Available	INNER TUB W/PLUG
16	215081		Poly Bag
17	206422		Wire Harness-DC
"	206849		D.C. Wire Harness
18	206418		Water Level Switch-Digital
19	Y313559		Screw
20	410296	596669	Clamp, Manifold
21	206405		Outer Tub
22	215258	22001616	Tube, Air
23	211641		Clamp, 1-1/16"
24	213045		Hose, Outer Tub Part Not Used
25	200900	616099	Clamp
26	205161	489503	Clamp
27	214434		Spout, Deflector
28	214495		Tube, Inlet To Tub
29	211210		Washer, Clamping Nut
30	Y015666		Washer, Retaining -
31	Y015667		Retaining Ring
32	215980		Plug, Filter Hole

