


Maytag SG7800 03 - CABINET & FRONT PANEL

SECTION: CABINET & FRONT PANEL
 MODEL: SE7800 SG7800



Issue Date: 12/90

24

Maytag [Residential Maytag SG7800 Stacked Washer and Dryer Parts](#) Parts Diagram 03 - CABINET & FRONT PANEL
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	210866			Nut, Twin Speed
2	211500			Washer, Bracket To Top Cover
3	213501			Screw, No.6-20 X 1-1/8 Inch
4	202476			Unbalance Switch
5	207797			Relay
6	215273			Clip, Spring Relay
7	207834	8566493		Power Relay
8	207784		Not Available	WIRE HARNESS
9	212949	22001866		Screw, Relay
10	207207		Not Available	CABINET WHT
11	Y059149			(7/8" I.D. CARTON OF 50 FT.)
"	215279	22003410		Hose, Drain
"	216017			Hose, Drain
12	200908	285655		Clamp, Hose
"	200461	285655		Clamp, Hose
13	Y014874			Screw, Idler Arm And Sleeve

14	214764	208847	Elbow
"	Y216016	W10116738	Elbow
15	214765		Gasket, Siphon Break
16	214765		Gasket, Siphon Break
17	202574	3367052	Clamp, Hose
18	215365	22001448	Hose, Pump
19	215711		Fastener, Spring
20	207205		Panel, Front
21	213123	22001496	Front Panel Fastener And Screw
22	211294	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
23	213846		Guard, Belt
24	213122	27001200	Screw
25	213280	204439	Screw And Fstner Assembly
26	213007		Xfor Cabinet See Cabinet, Back
27	207787	12002304	Switch-WL
28	214354		Screw, Top Cover To Cabnt.
37	Y216015		Coupling, Hose

