


# Maytag YMED5620TQ1 01 - TOP AND CONSOLE PARTS



## TOP AND CONSOLE PARTS

29" ELECTRIC DRYER

For Model: YMED5620TQ1  
(White)



10-07 Litho in U.S.A. (drd)

1

Part No. W10169068 Rev. A

Maytag Residential Maytag YMED5620TQ1 Dryer Parts Parts Diagram 01 - TOP AND CONSOLE PARTS  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	W10088770		Not Available	Guide, Use & Care
"	8578217		Not Available	Wiring Diagram
"	W10089170		Not Available	Sheet, Cycle Feature
2	<a href="#">W10112577</a>			Panel, Rear Console
3	<a href="#">693995</a>			Screw, Hex Head
4	W10086705	<a href="#">W10142666</a>		Console
5	W10112569	<a href="#">W10203949</a>		Medallion
6	<a href="#">8312709</a>			Clip-Console
7	<a href="#">694419</a>			Mini-Buzzer
8	8533971	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
9	<a href="#">3979617</a>			Timer, 60 Hz
10	<a href="#">3399639</a>			Switch, Rotary Temperature
11	<a href="#">W10117655</a>			Switch, Push-To-Start
12	<a href="#">W10110029</a>			Knob, Control
13	<a href="#">W10110030</a>			Timer Knob Assembly
14	<a href="#">8536939</a>			Clip, Knob

15	<a href="#">W10110861</a>		Wire, Jumper
16	<a href="#">W10113080</a>		Wire, Jumper
17	<a href="#">8565972</a>		Screen, Lint
18	688983	<a href="#">487240</a>	Screw, For Mtg. Service Capacitor
19	W10112597	<a href="#">W10112599</a>	Top
20	W10111002	Not Available	Harness, Wiring
21	337686	Not Available	SCREW, 8-18 X .500
22	<a href="#">W10112578</a>		Harness, Bracket
23	<a href="#">W10112603</a>		Seal, Harness
24	<a href="#">3395683</a>		Receptacle, Multi-Terminal
25	<a href="#">3394427</a>		Clip-Harness
26	<a href="#">3401144</a>		Connector
27	<a href="#">3397269</a>		Connector, Timer
28	<a href="#">3347243</a>		Block, Disconnect
29	<a href="#">94614</a>		Terminal
30	<a href="#">3936144</a>		Do-It-Yourself Repair Manuals

