


Maytag YMED5820TW0 01 - TOP AND CONSOLE PARTS



TOP AND CONSOLE PARTS

For Model: YMED5820TW0
(White)

29" ELECTRIC DRYER



9-07 Litho in U.S.A. (drd)

1

Part No. W10123415 Rev. B

Maytag Residential Maytag YMED5820TW0 Dryer Parts Parts Diagram 01 - TOP AND CONSOLE PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	W10089171		Not Available	Sheet, Cycle Feature
"	W10088770		Not Available	Guide, Use & Care
"	3406668		Not Available	Wiring Diagram
2	W10112576			Panel, Rear Console
3	693995			Screw, Hex Head
4	W10113080			Wire, Jumper
5	3406725			Timer Assembly
6	3405154			Switch Rotary
7	694419			Mini-Buzzer
8	8533971	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
9	8578354			Switch, Temperature
10	W10117655			Switch, Push-To-Start
11	W10086713	W10142692		Console
12	8312709			Clip-Console
13	W10112569	W10203949		Medallion
14	8536939			Clip, Knob

15	W10110035		Knob
16	W10110036		Knob
17	337686	Not Available	SCREW, 8-18 X .500
18	8565981		Bracket, Harness
19	W10118608		Foam-Seal Console Bracket
20	W10112267		Foam-Seal Control Bracket
21	237446	487596	Washer
22	3391885		Connector, Edge
23	8558178		Control, Electronic
24	343641	681414	Screw, 10AB X 1/2
25	W10115066	Not Available	Harness, Wiring
26	8565972		Screen, Lint
27	688983	487240	Screw, For Mtg. Service Capacitor
28	W10112599		Top
29	3395683		Receptacle, Multi-Terminal
30	3394427		Clip-Harness
31	3401144		Connector
32	3397269		Connector, Timer
33	3347243		Block, Disconnect
34	94614		Terminal
35	3936144		Do-It-Yourself Repair Manuals

