


# Maytag YMEDC700VW0 01 - TOP AND CONSOLE PARTS

**MAYTAG**

## TOP AND CONSOLE PARTS

27" ELECTRIC DRYER

For Models: YMEDC700VW0, YMEDC700VJ0  
(White/Grey) (Oxide)



11-08 Printed in U.S.A. (LT)(bay)

1

Part No. W10237942 Rev. A

Maytag Residential Maytag YMEDC700VW0 Dryer Parts Parts Diagram 01 - TOP AND CONSOLE PARTS

Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
2	8317305	<a href="#">285909</a>		Panel-Rear
3	<a href="#">8566184</a>			Timer Assembly
4	<a href="#">W10101390</a>			Badge Assembly
"	<a href="#">W10103431</a>			Badge Assembly
5	<a href="#">3398094</a>			Switch, Push To Start
6	<a href="#">3391885</a>			Connector, Edge
7	<a href="#">3395683</a>			Receptacle, Multi-Terminal
8	<a href="#">8578352</a>			Switch, Temperature
9	<a href="#">3405156</a>			Switch, Rotary
10	8533971	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
11	<a href="#">3347243</a>			Block, Disconnect
12	<a href="#">694419</a>			Mini-Buzzer
13	<a href="#">8536939</a>			Clip, Knob
14	<a href="#">8312709</a>			Clip-Console
15	8576583	<a href="#">W10119283</a>		Cover, Terminal Block
16	<a href="#">3397269</a>			Connector, Timer

17	3390814	<a href="#">90767</a>	Screw, 8A X 3/8 HeX Washer Head Tapping
18	<a href="#">W10180218</a>		Knob, Control Assembly
"	<a href="#">W10112582</a>		Knob, Control Assembly
19	W10206521	Not Available	Harness, Electric
20	<a href="#">W10180219</a>		Knob, Timer Assembly
"	<a href="#">W10112584</a>		Knob, Timer Assembly
21	<a href="#">W10180220</a>		Knob Assembly Push-To-Start
"	<a href="#">W10112586</a>		Knob Assembly Push-To-Start
22	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
23	<a href="#">3936144</a>		Do-It-Yourself Repair Manuals
24	8541355	<a href="#">3980403</a>	Top
"	<a href="#">W10212718</a>		Top
25	<a href="#">94614</a>		Terminal
26	<a href="#">693995</a>		Screw, Hex Head
27	<a href="#">W10086738</a>		Console And Bracket Assembly
"	<a href="#">W10086741</a>		Console And Bracket Assembly
28	<a href="#">3391018</a>		Tie Cable
29	<a href="#">8558178</a>		Control, Electronic
30	3390647	<a href="#">488729</a>	Screw
31	<a href="#">8568314</a>		Strap, Console
32	<a href="#">3394427</a>		Clip-Harness
33	<a href="#">W10193821</a>		Cap, End
"	<a href="#">W10101397</a>		Cap, End
34	<a href="#">W10193824</a>		Endcap Console Bracket
"	<a href="#">W10101398</a>		Cap, End

