


Maytag YMEDX600XW0 02 - CABINET PARTS



Maytag [Residential Maytag YMEDX600XW0 Dryer Parts](#) Parts Diagram 02 - CABINET PARTS
Click on the part number to view part

| Item | Original Part Number | Replaced By | Status | Part Description |
|------|---------------------------|---------------------------|--------|----------------------------------------|
| 1 | 697773 | 3395530 | | Screw |
| 2 | 693152 | | | Bumper, Console |
| 3 | 3390647 | 488729 | | Screw |
| 4 | 3397659 | | | Block, Terminal |
| 5 | W10246525 | W10314253 | | Switch, Assembly Broken Belt |
| 6 | W10312811 | | | Seal, Spill Guard |
| 7 | 8310656 | | | Cabinet |
| 8 | 3392100 | 49621 | | Feet-Leveling |
| NI | 279810 | | | Foot-Optional |
| 9 | 660658 | | | Clamp, Motor Mounting 343481 685441 |
| 10 | 3387374 | | | Spring, Idler |
| 11 | 3389420 | | | Retainer-Idler 1/4-20 X 1/16 |
| 12 | W10331132 | | | Dryer Exhaust Kit |
| 13 | 3388672 | 279640 | | Pulley-ldr |
| 14 | 279318 | | | Terminal Tinned And Brass Panel |

| | | | |
|----|---------------------------|---------------------------|-------------------------------|
| 15 | 3390646 | W10139210 | Screw, 8-18 X 5/16 |
| 16 | 694091 | | Trim, Side Right Hand |
| 17 | 3392538 | 279570 | Latch |
| 18 | 690997 | | Washer, Thrust |
| 19 | W10291934 | | Clip |
| 20 | W10121334 | | Washer, Thrust |
| 21 | 3389247 | | Hinge And Pin Assembly |
| 22 | 342055 | 488627 | Screw |
| 23 | W10307570 | W10336128 | Seal, Spill Guard |
| 24 | 3394331 | | Plate Cover |
| 25 | 8563747 | | Exhaust Pipe Medium Pipe |
| 26 | 697215 | 3406797 | Toe Panel |
| 27 | W10281085 | W10396038 | Motor Assembly 60 Hz |
| 28 | 49026 | | 4" - 90° Elbow |
| 29 | 3389729 | | Pulley, Motor |
| 30 | W10112954 | | Belt, Drive |
| 31 | W10192860 | W10273971 | Screw, 6-19 X 1/2 |
| 32 | W10242878 | | Bracket, Motor Mounting |
| 33 | 279393 | | Terminal Block Screw Kit |
| 34 | W10236068 | | Bracket, Cabinet |
| 35 | 8563750 | | Exhaust Pipe |
| 36 | W10284182 | | Door Handle |
| 37 | 8563749 | | Exhaust Pipe |
| 38 | 343641 | 681414 | Screw, 10AB X 1/2 |
| 39 | 3388674 | W10118756 | Idler Bracket |
| 40 | 3357011 | 308685 | Side Trim) |
| 41 | 3406107 | | Door Switch Assembly |
| 42 | 3387242 | | Seal, Front Panel |
| 43 | 3388229 | | Retainer, Toe Panel |
| 44 | 3392563 | 280083 | Door-Rear |
| 45 | 3393657 | | Restrainer, Belt |
| 46 | W10279721 | | Door, Front |
| 47 | W10115218 | | Front Panel |
| 48 | 696144 | 279570 | Latch |
| 49 | 3393008 | 308685 | Side Trim) |
| 50 | 3390735 | | Seal, Door |
| 51 | 3390902 | | Clip, Door Hinge |
| 52 | 3389249 | | Nut, Inner Door |
| 53 | W10191265 | | Plug, Hinge Screw Front Panel |
| 54 | W10294344 | | Spacer, Door Mount |
| 55 | W10186596 | W10470674 | Dryer Exhaust Kit |