


Maytag YMET3800XW0 01 - WASHER/DRYER CONTROL PANEL PARTS



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST
 3-11 Litho in U.S.A. (LT)(bay) 1 Part No. W10407530 Rev. A

Maytag Residential Maytag YMET3800XW0 Washer/Dryer Parts Parts Diagram 01 - WASHER/DRYER CONTROL
 PANEL PARTS

Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	W10356098		Not Available	INSTALLATION INSTRUCTIONS
"	W10343072		Not Available	USE & CARE GUIDE
"	W10364012		Not Available	WIRING DIAGRAM
2	3390688			Spacer- Foam Pad
3	8528583			Bracket, Control
4	W10124193			Timer, Washer
5	3389464			End Cap
6	W10112571			Dial,
7	W10110033			Knob, Timer
8	W10110035			Knob
9	8521965			Gasket, Console
10	8558178			Control, Electronic
11	W10110036			Knob
12	3400808			Screw. Mounting
13	W10400878	W10510877		WL Switch

14	W10114118		Switch, Temperature
15	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
16	W10117655		Switch, Push-To-Start
17	W10400880	W10510877	WL Switch
18	694419		Mini-Buzzer
19	W10113816		Timer, Dryer
20	W10339548		Panel, Control
21	3389453		Bracket, Hinge
22	3389456		End Cap
23	W10371544	Not Available	HARNES - DRYER
24	3390604		Clamp, Harness
25	3390422	W10134185	Clip, Harness
26	8536939		Clip, Knob
27	W10210799		Clip, Harness
28	8524808		Fitting, Pressure Hose "T"
29	W10368080		Hose, Pressure Switch
30	W10334336		Cable Tie

