


Norge DEF181W 01 - CONTROL PANEL (ORIG. REV. A-F)



Norge [Residential Norge DEF181W Dryer Parts](#) Parts Diagram 01 - CONTROL PANEL (ORIG. REV. A-F)
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	53-0819		Not Available	CONTROL PANEL
2	25-7649	910187		Screw
"	25-7702			Speedclip, End Cap To Control Panel
"	53-0264			RH Endcap
"	53-0265			LH Endcap
3	25-7851			Speedclip, End Cap To Top
"	25-7697	25-2219		Screw
4	25-7435	33002917		Screw, No.10-16
"	25-7852			Speedclip, Rr Shld To End Cap
5	53-0280		Not Available	TRIM, END CAP (LT)
"	53-0279		Not Available	TRIM, END CAP (RT)
6	25-7760			Screw
7	25-7702			Speedclip, End Cap To Control Panel
8	25-3092	90767		Screw, 8A X 3/8 HeX Washer Head Tapping

9	53-0365	53-1676	Shield, Control
10	53-0268	21001460	Shield, Rear
"	25-3457		Screw, Sems
"	25-3457		Screw, Sems
11	53-0661	Not Available	TIMER
"	53-0379	Not Available	TIMER
12	53-0670	Not Available	KNOB/SKIRT ASM
"	53-0729	Not Available	TIMER KNOB ASM
"	25-0205	216412	Screw, Bracket To Timer
"	53-0472	Not Available	TIMER KNOB
13	53-0651	Not Available	TIMER KNOB
"	35-0267	Not Available	TIMER KNOB
"	53-0652	Not Available	TIMER KNOB
"	25-6044		Set Screw
14	35-0092	Not Available	SKIRT ASM
15	25-3092	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
"	53-0456		Switch, Selector
16	35-0316	21001283	Knob, Selector----Piq
"	35-0167	21001283	Knob, Selector----Piq

