


Norge DEK204AC 01 - CONTROL PANEL (ORIG. REV. A)



Norge Residential Norge DEK204AC Dryer Parts Parts Diagram 01 - CONTROL PANEL (ORIG. REV. A)
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	25-7649	910187		Screw
"	25-7702			Speedclip, End Cap To Control Panel
"	53-0820		Not Available	CONTROL PANEL
2	53-0265			LH Endcap
3	25-7760			Screw
"	53-0264			RH Endcap
"	53-0277		Not Available	TRIM, END CAP (RT)
"	53-0278		Not Available	TRIM, END CAP (LT)
4	25-3092	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
"	25-7702			Speedclip, End Cap To Control Panel
"	53-0365	53-1676		Shield, Control
5	25-0088	489483		Screw 10-32 X 1/2
"	53-0883		Not Available	TIMER
"	63-6752		Not Available	TIMER MOTOR

6	25-6044		Set Screw
"	53-0653	31001219	Knob Ski
7	35-0168		Not Available
			SELECTOR KNOB
8	25-3092	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
"	63-6731	53-1639	Buzzer Assembly
9	25-7702		Speedclip, End Cap To Control Panel
10	53-0394	53-1264	Rotary Switch
"	25-3092	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
11	34-9487		Not Available
			PLATE, REINFORCEMENT
"	25-3092	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
"	25-7435	33002917	Screw, No.10-16
"	25-7697	25-2219	Screw
"	25-7852		Speedclip, Rr Shld To End Cap
"	53-0268	21001460	Shield, Rear
"	25-7851		Speedclip, End Cap To Top
12	63-6743	31001484	Resistor Assembly

