


Norge DEL202WC 01 - CONTROL PANEL (ORIG. REV. A-B)



Norge Residential Norge DEL202WC Dryer Parts Parts Diagram 01 - CONTROL PANEL (ORIG. REV. A-B)
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	53-1285		Not Available	CONTROL PANEL
2	53-0264			RH Endcap
"	25-7649	910187		Screw
"	25-7702			Speedclip, End Cap To Control Panel
"	53-0265			LH Endcap
3	25-7697	25-2219		Screw
"	25-7851			Speedclip, End Cap To Top
4	25-7435	33002917		Screw, No.10-16
"	25-7852			Speedclip, Rr Shld To End Cap
5	53-0279		Not Available	TRIM, END CAP (RT)
"	53-0280		Not Available	TRIM, END CAP (LT)
6	25-7760			Screw
7	25-7702			Speedclip, End Cap To Control Panel
8	25-3092	90767		Screw, 8A X 3/8 HeX Washer Head Tapping

9	53-0365	53-1676	Shield, Control
10	53-0268	21001460	Shield, Rear
"	25-3457		Screw, Sems
"	25-3092	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
11	53-0635	Not Available	TIMER MOTOR
"	53-1364		Timer
"	53-1549	Not Available	TIMER
12	25-0205	216412	Screw, Bracket To Timer
13	53-1290	Not Available	SKIRT, TIMER
14	53-1530	31001219	Knob Ski
15	53-0456		Switch, Selector
"	25-3092	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
16	63-6731	53-1639	Buzzer Assembly
"	35-2186	Not Available	KNOB, SELECTOR

