


# Norge DEL203AC 01 - CONTROL PANEL (REV. A-D)

NORGE DEL203C BACKGUARD



ISSUED 8/89

Norge Residential Norge DEL203AC Dryer Parts Parts Diagram 01 - CONTROL PANEL (REV. A-D)

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">53-1284</a>			Control Panel
2	35-2488	<a href="#">21001452</a>		Cap- End
"	25-7649	<a href="#">910187</a>		Screw
"	<a href="#">25-7702</a>			Speedclip, End Cap To Control Panel
"	35-2487	<a href="#">21001451</a>		Cap- End
"	<a href="#">53-0264</a>			RH Endcap
"	<a href="#">53-0265</a>			LH Endcap
3	<a href="#">25-7851</a>			Speedclip, End Cap To Top
"	25-7697	<a href="#">25-2219</a>		Screw
4	25-7435	<a href="#">33002917</a>		Screw, No.10-16
"	<a href="#">25-7852</a>			Speedclip, Rr Shld To End Cap
5	53-0277		Not Available	TRIM, END CAP (RT)
"	53-0278		Not Available	TRIM, END CAP (LT)
6	<a href="#">25-7760</a>			Screw
7	<a href="#">25-7702</a>			Speedclip, End Cap To Control

	<a href="#">25-1192</a>		Panel
8	25-3092	<a href="#">90767</a>	Screw, 8A X 3/8 HeX Washer Head Tapping
9	<a href="#">53-1676</a>		Shield, Control
"	53-0365	<a href="#">53-1676</a>	Shield, Control
10	35-2688	<a href="#">21001460</a>	Shield, Rear
"	25-3092	<a href="#">90767</a>	Screw, 8A X 3/8 HeX Washer Head Tapping
"	<a href="#">25-3457</a>		Screw, Sems
"	53-0268	<a href="#">21001460</a>	Shield, Rear
11	<a href="#">53-1758</a>		Timer
"	63-6752	Not Available	TIMER MOTOR
"	53-1363	Not Available	TIMER
12	25-0205	<a href="#">216412</a>	Screw, Bracket To Timer
"	25-7435	<a href="#">33002917</a>	Screw, No.10-16
13	53-1290	Not Available	SKIRT, TIMER
14	53-1530	<a href="#">31001219</a>	Knob Ski
15	53-1265	Not Available	ROTARY SWITCH
"	25-3092	<a href="#">90767</a>	Screw, 8A X 3/8 HeX Washer Head Tapping
16	63-6743	<a href="#">31001484</a>	Resistor Assembly
"	35-2186	Not Available	KNOB, SELECTOR
"	63-6731	<a href="#">53-1639</a>	Buzzer Assembly

