


Norge DEL203W 02 - CONTROL PANEL (REV. E-G)



ISSUED 6/89

Norge [Residential Norge DEL203W Dryer Parts](#) Parts Diagram 02 - CONTROL PANEL (REV. E-G)

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	25-7702			Speedclip, End Cap To Control Panel
"	25-7793			Screw
"	53-1284			Control Panel
2	35-2488	21001452		Cap- End
"	25-7760			Screw
"	35-2487	21001451		Cap- End
"	53-0277		Not Available	TRIM, END CAP (RT)
"	53-0278		Not Available	TRIM, END CAP (LT)
3	25-7702			Speedclip, End Cap To Control Panel
"	25-3092	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
"	53-1676			Shield, Control
4	63-6752		Not Available	TIMER MOTOR
"	25-7435	33002917		Screw, No.10-16
"	53-1758			Timer

"	53-1303		Not Available	TIMER
"	25-0205	216412		Screw, Bracket To Timer
5	53-1357	31001219		Knob Ski
"	25-6044			Set Screw
6	35-2186		Not Available	KNOB, SELECTOR
7	63-6731	53-1639		Buzzer Assembly
"	25-3092	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
"	25-7702			Speedclip, End Cap To Control Panel
8	25-3092	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
"	53-1265		Not Available	ROTARY SWITCH
9	25-3092	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
"	25-7697	25-2219		Screw
"	63-6743	31001484		Resistor Assembly
"	25-7851			Speedclip, End Cap To Top
"	34-9487		Not Available	PLATE, REINFORCEMENT
"	35-2688	21001460		Shield, Rear
10	53-1447-2		Not Available	MANUAL, USE & CARE
"	53-1447		Not Available	MANUAL, USE & CARE
11	63-5577-1		Not Available	MANUAL, USE & CARE

