


Norge DEM202A 01 - CONTROL PANEL (REV. A-D)

SECTION: BACKGUARD
 MODEL: DEM202



Issue Date: 8/90

Norge [Residential Norge DEM202A Dryer Parts](#) Parts Diagram 01 - CONTROL PANEL (REV. A-D)
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	53-2306		Not Available	CONTROL PANEL
"	53-1613		Not Available	CONTROL PANEL
2	35-2488	21001452		Cap- End
"	25-7649	910187		Screw
"	25-7697	25-2219		Screw
"	25-7702			Speedclip, End Cap To Control Panel
"	25-7851			Speedclip, End Cap To Top
"	35-2487	21001451		Cap- End
"	53-0264			RH Endcap
"	53-0265			LH Endcap
3	25-7851			Speedclip, End Cap To Top
"	25-7697	25-2219		Screw
4	25-7435	33002917		Screw, No.10-16
"	25-7852			Speedclip, Rr Shld To End Cap
5	53-0280		Not Available	TRIM, END CAP (LT)

"	53-0279	Not Available	TRIM, END CAP (RT)
6	25-7760		Screw
7	25-7702		Speedclip, End Cap To Control Panel
8	25-3092	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
9	53-0365	53-1676	Shield, Control
"	53-1676		Shield, Control
10	53-0268	21001460	Shield, Rear
"	35-2688	21001460	Shield, Rear
11	63-6752	Not Available	TIMER MOTOR
"	63-6743	31001484	Resistor Assembly
"	53-1547		Timer
"	53-1803		Timer
12	25-7435	33002917	Screw, No.10-16
"	25-0205	216412	Screw, Bracket To Timer
13	53-1530	31001219	Knob Ski
14	53-1290	Not Available	SKIRT, TIMER
15	53-1267	53-0456	Switch, Selector
"	25-3092	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
16	35-2186	Not Available	KNOB, SELECTOR
"	63-6731	53-1639	Buzzer Assembly
"	25-3092	90767	Screw, 8A X 3/8 HeX Washer Head Tapping

the laundry company®

the laundry company®