


Norge DEM202WC 02 - CONTROL PANEL (REV. A-D)

SECTION: BACKGUARD
MODEL: DEM202C



Issue Date: 6/90

Norge Residential Norge DEM202WC Dryer Parts Parts Diagram 02 - CONTROL PANEL (REV. A-D)
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	53-2306		Not Available	CONTROL PANEL
"	53-1613		Not Available	CONTROL PANEL
2	53-0264			RH Endcap
"	25-7649	910187		Screw
"	25-7702			Speedclip, End Cap To Control Panel
"	35-2487	21001451		Cap- End
"	35-2488	21001452		Cap- End
"	53-0265			LH Endcap
3	25-7851			Speedclip, End Cap To Top
"	25-7697	25-2219		Screw
4	25-7435	33002917		Screw, No.10-16
"	25-7852			Speedclip, Rr Shld To End Cap
5	53-0279		Not Available	TRIM, END CAP (RT)
"	53-0280		Not Available	TRIM, END CAP (LT)
6	25-7760			Screw

7	25-7702		Speedclip, End Cap To Control Panel
8	25-3092	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
9	53-1676		Shield, Control
"	53-0365	53-1676	Shield, Control
10	25-3092	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
"	35-2688	21001460	Shield, Rear
"	53-0268	21001460	Shield, Rear
11	53-1803		Timer
"	53-0635	Not Available	TIMER MOTOR
"	53-1549	Not Available	TIMER
12	25-7435	33002917	Screw, No.10-16
"	25-0205	216412	Screw, Bracket To Timer
13	53-1290	Not Available	SKIRT, TIMER
14	53-1530	31001219	Knob Ski
15	53-1267	53-0456	Switch, Selector
"	25-3092	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
16	63-6731	53-1639	Buzzer Assembly
"	35-2186	Not Available	KNOB, SELECTOR
NI	53-1446	Not Available	MANUAL, USE & CARE

