


Norge DEM204 01 - CONTROL PANEL (REV. A-C)

SECTION: BACKGUARD
MODEL: DEM204



Issue Date: 6/90

Norge Residential Norge DEM204 Dryer Parts Parts Diagram 01 - CONTROL PANEL (REV. A-C)
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	25-7702			Speedclip, End Cap To Control Panel
"	25-7649	910187		Screw
"	53-1283		Not Available	CONTROL PANEL
2	53-0278		Not Available	TRIM, END CAP (LT)
"	53-0264			RH Endcap
"	53-0265			LH Endcap
"	53-0277		Not Available	TRIM, END CAP (RT)
3	25-3092	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
"	25-7702			Speedclip, End Cap To Control Panel
"	53-0323		Not Available	CONTROL SHIELD
4	53-1300		Not Available	TIMER
"	63-5685	63-5613		Timer
5	25-6044			Set Screw
"	53-1530	31001219		Knob Ski

6	35-2186		Not Available	KNOB, SELECTOR
7	25-3092	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
"	63-6731	53-1639		Buzzer Assembly
8	25-7702			Speedclip, End Cap To Control Panel
9	25-3092	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
"	53-1263			Rotary Switch
10	25-7435	33002917		Screw, No.10-16
"	25-7851			Speedclip, End Cap To Top
"	25-7852			Speedclip, Rr Shld To End Cap
"	34-9487		Not Available	PLATE, REINFORCEMENT
"	53-0268	21001460		Shield, Rear
11	25-7712		Not Available	SCREW
"	33-6621		Not Available	BRACKET, SWITCH
"	33-8541		Not Available	SWITCH PAD
"	63-6743	31001484		Resistor Assembly
"	53-1296			Switch
"	35-0385			Pushbutton
12	53-1448		Not Available	MANUAL, USE & CARE

