


Norge DEN204KV 02 - CONTROL PANEL (DEN204KV)



Norge Residential Norge DEN204KV Dryer Parts Parts Diagram 02 - CONTROL PANEL (DEN204KV)
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	31001012		Not Available	PANEL, CONTROL
"	25-3457			Screw, Sems
2	25-7793			Screw
3	25-7702			Speedclip, End Cap To Control Panel
4	53-0278		Not Available	TRIM, END CAP (LT)
"	53-0277		Not Available	TRIM, END CAP (RT)
5	25-7760			Screw
6	35-2669		Not Available	CAP, END (LT)(WHT)
"	35-2668	21001453		Cap- End
7	53-2504	31001193		Pad, Shield
"	53-1676			Shield, Control
"	25-3092	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
"	31001128		Not Available	SHIELD, CONTROL
8	31001027		Not Available	TIMER
"	31001069	31001514		Resistor Assembly

9	25-7435	33002917	Screw, No.10-16
10	31001129		Switch, Temperature
"	53-0344	Not Available	SWITCH, TEMPERATURE
11	53-0346	53-1263	Rotary Switch
"	25-3092	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
"	31001190		Switch, Two Position Rotary
12	25-7852		Speedclip, Rr Shld To End Cap
13	53-2638	Not Available	KNOB & SKIRT ASSY (WHT)
14	35-2940	21001239	Knob, Selector
15	25-3457		Screw, Sems
"	25-3092	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
"	35-2688	21001460	Shield, Rear
16	25-7851		Speedclip, End Cap To Top
"	25-2219		Screw
NI	31001034	Not Available	MANUAL, USE & CARE
17	31001008		Manual, Use And Care
NI	16002081	Not Available	GUIDE, QUICK REF - NORGE

