


# Norge DEN204V 02 - CONTROL PANEL (DEN204V)



Norge [Residential Norge DEN204V Dryer Parts](#) Parts Diagram 02 - CONTROL PANEL (DEN204V)  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	31001024		Not Available	PANEL, CONTROL
2	25-3092	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
"	35-2669		Not Available	CAP, END (LT)(WHT)
"	35-2668	<a href="#">21001453</a>		Cap- End
3	<a href="#">25-7702</a>			Speedclip, End Cap To Control Panel
4	<a href="#">53-1639</a>			Buzzer Assembly
"	25-3092	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
5	53-0277		Not Available	TRIM, END CAP (RT)
"	53-0278		Not Available	TRIM, END CAP (LT)
6	<a href="#">25-7760</a>			Screw
7	<a href="#">25-7851</a>			Speedclip, End Cap To Top
8	25-7649	<a href="#">910187</a>		Screw
9	53-2504	<a href="#">31001193</a>		Pad, Shield
"	<a href="#">53-1676</a>			Shield, Control

"	31001128		Not Available	SHIELD, CONTROL
10	35-2688	<a href="#">21001460</a>		Shield, Rear
11	63-6743	<a href="#">31001484</a>		Resistor Assembly
"	53-1816		Not Available	TIMER
12	31001119	<a href="#">W10116760</a>		Screw
13	53-2638		Not Available	KNOB & SKIRT ASSY (WHT)
14	25-3092	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
"	<a href="#">31001129</a>			Switch, Temperature
"	53-0344		Not Available	SWITCH, TEMPERATURE
15	35-2940	<a href="#">21001239</a>		Knob, Selector
16	25-3092	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
"	53-0346	<a href="#">53-1263</a>		Rotary Switch
"	<a href="#">31001190</a>			Switch, Two Position Rotary
NI	<a href="#">31001008</a>			Manual, Use And Care
17	31001035		Not Available	MANUAL, USE & CARE
"	16002081		Not Available	GUIDE, QUICK REF - NORGE

