


Norge DGL203A 01 - CONTROL PANEL (REV. E-G)



Norge [Residential Norge DGL203A Dryer Parts](#) Parts Diagram 01 - CONTROL PANEL (REV. E-G)
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	53-1284			Control Panel
2	35-2488	21001452		Cap- End
"	25-7649	910187		Screw
"	25-7702			Speedclip, End Cap To Control Panel
"	35-2487	21001451		Cap- End
3	25-7851			Speedclip, End Cap To Top
"	25-7697	25-2219		Screw
4	25-7435	33002917		Screw, No.10-16
5	53-0277		Not Available	TRIM, END CAP (RT)
"	53-0278		Not Available	TRIM, END CAP (LT)
6	25-7760			Screw
7	25-7702			Speedclip, End Cap To Control Panel
8	25-3092	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
9	53-1676			Shield, Control

10	35-2688	21001460	Shield, Rear
"	25-3457		Screw, Sems
"	25-3092	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
11	53-1303		Not Available
"	53-1758		TIMER
"	63-6752		Not Available
12	25-0205	216412	Screw, Bracket To Timer
"	25-7435	33002917	Screw, No.10-16
13	53-1290		Not Available
14	53-1530	31001219	SKIRT, TIMER
15	25-3092	90767	Knob Ski
"	53-1265		Not Available
16	35-2186		Not Available
"	63-6731	53-1639	Screw, 8A X 3/8 HeX Washer Head Tapping
17	53-1447-2		Not Available
"	63-5577		Not Available
"	53-1447		Not Available

