


Norge DGL203WC 02 - CONTROL PANEL (ORIG. REV. A-D)

SECTION: BACKGUARD
 MODEL: DGL203C



Issue Date: 11/90

Norge Residential Norge DGL203WC Dryer Parts Parts Diagram 02 - CONTROL PANEL (ORIG. REV. A-D)
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	53-1284			Control Panel
2	53-0264			RH Endcap
"	25-7649	910187		Screw
"	25-7702			Speedclip, End Cap To Control Panel
"	35-2487	21001451		Cap- End
"	35-2488	21001452		Cap- End
"	53-0265			LH Endcap
3	25-7697	25-2219		Screw
"	25-7851			Speedclip, End Cap To Top
4	25-7852			Speedclip, Rr Shld To End Cap
"	25-7435	33002917		Screw, No.10-16
5	53-0278		Not Available	TRIM, END CAP (LT)
"	53-0277		Not Available	TRIM, END CAP (RT)
6	25-7760			Screw
7	25-7702			Speedclip, End Cap To Control

	25-1192			Panel
8	25-3092	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
9	53-1676			Shield, Control
"	53-0365	53-1676		Shield, Control
10	25-3092	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
"	25-3457			Screw, Sems
"	35-2688	21001460		Shield, Rear
"	53-0268	21001460		Shield, Rear
11	53-0635		Not Available	TIMER MOTOR
"	53-1303		Not Available	TIMER
"	53-1758			Timer
12	25-7435	33002917		Screw, No.10-16
"	25-0205	216412		Screw, Bracket To Timer
"	53-1530	31001219		Knob Ski
13	53-1290		Not Available	SKIRT, TIMER
14	53-1289		Not Available	KNOB TIMER
15	25-3092	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
"	53-1265		Not Available	ROTARY SWITCH
16	63-6731	53-1639		Buzzer Assembly
"	35-2186		Not Available	KNOB, SELECTOR
17	53-1447		Not Available	MANUAL, USE & CARE
"	63-5577		Not Available	MANUAL, USE & CARE

the laundry company[®]

the laundry company[®]