


Norge DGL203WC 03 - CONTROL PANEL (REV. E)



Norge Residential Norge DGL203WC Dryer Parts Parts Diagram 03 - CONTROL PANEL (REV. E)
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	53-1284			Control Panel
2	35-2487	21001451		Cap- End
"	25-7649	910187		Screw
"	25-7697	25-2219		Screw
"	25-7702			Speedclip, End Cap To Control Panel
"	35-2488	21001452		Cap- End
3	25-7697	25-2219		Screw
"	25-7851			Speedclip, End Cap To Top
4	25-3092	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
"	53-1639			Buzzer Assembly
5	53-0278		Not Available	TRIM, END CAP (LT)
"	53-0277		Not Available	TRIM, END CAP (RT)
6	25-7760			Screw
7	25-7702			Speedclip, End Cap To Control Panel

8	25-3092	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
9	53-1676		Shield, Control
10	35-2688	21001460	Shield, Rear
11	53-1758		Timer
12	25-7435	33002917	Screw, No.10-16
13	53-1530	31001219	Knob Ski
14	25-3092	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
"	53-0344	Not Available	SWITCH, TEMPERATURE
15	35-2186	Not Available	KNOB, SELECTOR
16	53-1447-2	Not Available	MANUAL, USE & CARE

Howes
the laundry company®

Howes
the laundry company®

Howes
the laundry company®