


# Norge DGN204W 02 - CONTROL PANEL



Norge Residential Norge DGN204W Dryer Parts Parts Diagram 02 - CONTROL PANEL  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	31001023		Not Available	PANEL, CONTROL
2	35-2488	<a href="#">21001452</a>		Cap- End
"	25-3092	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
"	35-2487	<a href="#">21001451</a>		Cap- End
3	<a href="#">25-7702</a>			Speedclip, End Cap To Control Panel
4	<a href="#">53-1639</a>			Buzzer Assembly
"	25-3092	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
5	53-0278		Not Available	TRIM, END CAP (LT)
"	53-0277		Not Available	TRIM, END CAP (RT)
6	<a href="#">25-7760</a>			Screw
7	<a href="#">25-7851</a>			Speedclip, End Cap To Top
8	25-7649	<a href="#">910187</a>		Screw
9	53-2504	<a href="#">31001193</a>		Pad, Shield
"	<a href="#">53-1676</a>			Shield, Control

"	31001128		Not Available	SHIELD, CONTROL
10	35-2688	<a href="#">21001460</a>		Shield, Rear
11	53-1816		Not Available	TIMER
12	31001119	<a href="#">W10116760</a>		Screw
13	53-2637	<a href="#">31001219</a>		Knob Ski
14	25-3092	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
"	<a href="#">31001129</a>			Switch, Temperature
"	53-0344		Not Available	SWITCH, TEMPERATURE
15	35-4244	<a href="#">21001283</a>		Knob, Selector----Piq
16	25-3092	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
"	53-0346	<a href="#">53-1263</a>		Rotary Switch
"	<a href="#">31001190</a>			Switch, Two Position Rotary
17	<a href="#">31001008</a>			Manual, Use And Care
"	31001035		Not Available	MANUAL, USE & CARE
"	16002081		Not Available	GUIDE, QUICK REF - NORGE

