

Norge LWM202A 04 - CONTROL PANEL (REV. A-D)



Norge Residential Norge LWM202A Washer Parts Parts Diagram 04 - CONTROL PANEL (REV. A-D)
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	25-7793			Screw
"	25-7702			Speedclip, End Cap To Control Panel
"	35-2559		Not Available	PANEL, CONTROL
2	53-0265			LH Endcap
"	53-0264			RH Endcap
"	35-2488	21001452		Cap- End
"	35-2487	21001451		Cap- End
3	34-9487		Not Available	PLATE, REINFORCEMENT
"	25-7851			Speedclip, End Cap To Top
"	25-7697	25-2219		Screw
4	25-7852			Speedclip, Rr Shld To End Cap
"	W10124350		Not Available	NOT REQUIRED PART OR SEE NOTE
"	25-7435	33002917		Screw, No.10-16
5	53-0279		Not Available	TRIM, END CAP (RT)

"	53-0280	Not Available	TRIM, END CAP (LT)
6	25-7760		Screw
7	25-3092	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
8	25-7702		Speedclip, End Cap To Control Panel
9	53-1676		Shield, Control
"	53-0365	53-1676	Shield, Control
10	35-2688	21001460	Shield, Rear
"	25-3092	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
"	53-0268	21001460	Shield, Rear
"	25-3457		Screw, Sems
11	35-2210	35-2749	Timer
12	25-0088	489483	Screw 10-32 X 1/2
13	35-2255	21001497	Skirt Ri
14	35-2485	12500058	Knob Ski
15	25-3092	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
"	35-0119		Rotary Switch
16	25-3092	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
"	35-2186	Not Available	KNOB, SELECTOR
17	25-3092	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
"	35-2356	Not Available	MANUAL, U&C INSERT
"	35-2145	21001554	Switch, Water Level

the laundry company[®]

the laundry company[®]