


Norge LWM204WC 02 - CONTROL PANEL



Norge [Residential Norge LWM204WC Washer Parts](#) Parts Diagram 02 - CONTROL PANEL
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	35-2177		Not Available	CONTROL PANEL
"	25-7649	910187		Screw
2	35-2488	21001452		Cap- End
"	35-2487	21001451		Cap- End
3	25-7435	33002917		Screw, No.10-16
4	53-0278		Not Available	TRIM, END CAP (LT)
"	53-0277		Not Available	TRIM, END CAP (RT)
5	25-7760			Screw
6	34-9487		Not Available	PLATE, REINFORCEMENT
"	25-7697	25-2219		Screw
"	25-7851			Speedclip, End Cap To Top
7	25-7702			Speedclip, End Cap To Control Panel
8	25-3092	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
9	53-1677		Not Available	CONTROL SHIELD
10	25-3457			Screw, Sems

"	25-7583		Not Available	PLASTIC NUT
"	25-3092	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
"	35-2688	21001460		Shield, Rear
11	35-2748		Not Available	TIMER
12	25-0205	216412		Screw, Bracket To Timer
13	35-2255	21001497		Skirt Ri
14	35-2485	12500058		Knob Ski
15	35-2197			Switch
16	25-3092	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
"	33-6620		Not Available	BRACKET
17	33-8540		Not Available	SWITCH PAD
18	25-3092	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
"	35-3283	21001554		Switch, Water Level
19	35-2186		Not Available	KNOB, SELECTOR
20	35-2588		Not Available	PUSHBUTTON - BLACK

