


Norge LWP222V 03 - CONTROL PANEL



Norge [Residential Norge LWP222V Washer Parts](#) Parts Diagram 03 - CONTROL PANEL
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	25-7702			Speedclip, End Cap To Control Panel
"	21001264		Not Available	PANEL, CONTROL (WHT)
"	25-7649	910187		Screw
2	35-2668	21001453		Cap- End
"	35-2669		Not Available	CAP, END (LT)(WHT)
3	25-7851			Speedclip, End Cap To Top
"	25-7697	25-2219		Screw
4	25-7852			Speedclip, Rr Shld To End Cap
"	25-7435	33002917		Screw, No.10-16
5	31001055		Not Available	TRIM, ENDCAP (LT WHT)
"	31001054		Not Available	TRIM, ENDCAP (RT WHT)
6	25-7760			Screw
7	25-3092	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
8	25-7702			Speedclip, End Cap To Control Panel

9	31001193		Pad, Shield
"	31001128	Not Available	SHIELD, CONTROL
10	25-3092	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
"	35-2688	21001460	Shield, Rear
11	21001341		Timer
"	35-3840		Timer
12	31001029	3400094	Screw, 10-32 X 3/8
13	21001238	21001502	Skirt Ri
14	21001237		Knob, Timer
15	21001139		Switch, Water Temp. 3 Position
"	25-3092	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
16	21001239		Knob, Selector
17	35-3691	21001554	Switch, Water Level
"	25-3092	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
18	21001274	Not Available	MANUAL, USE & CARE
"	21001033	Not Available	MANUAL, USE & CARE
19	16002081	Not Available	GUIDE, QUICK REF - NORGE

