


# Roper RGD4640YQ0 01 - TOP AND CONSOLE PARTS



## TOP AND CONSOLE PARTS

For Model: RGD4640YQ0  
(White)

29" GAS DRYER



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

1-12 Litho in U.S.A. (JLP)(bay)

1

Part No W10480396 Rev A

Roper Residential Roper RGD4640YQ0 Dryer Parts Parts Diagram 01 - TOP AND CONSOLE PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	W10096991		Not Available	GUIDE, USE & CARE
"	W10115228		Not Available	INSTRUCTIONS, INSTALLATION
"	W10185990		Not Available	WIRING DIAGRAM
2	<a href="#">693995</a>			Screw, Hex Head
3	<a href="#">8312709</a>			Clip-Console
4	<a href="#">357213</a>			Nut, Push-In
5	<a href="#">W10416486</a>			Panel, Rear Console
6	<a href="#">8558463</a>			HAndle And Lint Screen Assembly
7	<a href="#">8536939</a>			Clip, Knob
8	688983	<a href="#">487240</a>		Screw, For Mtg. Service Capacitor
9	8559800	<a href="#">8563663</a>		Top
10	<a href="#">W10453948</a>			Knob, Assembly Push-To-Start
11	<a href="#">W10436306</a>			Timer
12	<a href="#">W10450287</a>			Harness, Wiring

13	3348629	<a href="#">90767</a>	Screw, 8A X 3/8 HeX Washer Head Tapping
14	<a href="#">W10420741</a>		Switch, Push To Start
15	<a href="#">W10453946</a>		Timer Knob Assembly
16	W10096999	Not Available	PANEL, CONTROL

